

TABLE OF CONTENTS

Welcome Aboard	i
Dangers, Warnings & Cautions	ii
Boating Safety	1-1
Common Sense Approach.....	2-1
Rules of the Open Water	3-1
Guide to Individual Models	4-1
Instrument Gauges and Switches.....	5-1
Using Care While Fueling.....	6-1
Safety Checks and Services.....	7-1
New Boat Break-In	8-1
Starting and Basic Operations.....	9-1
Operational Hints.....	10-1
Lifting the Boat.....	11-1
Corrosion	12-1
Cleaning the Boat	13-1
Scheduled Maintenance Checks & Services.....	14-1
Scheduled Maintenance	15-1
Battery Connections and Hold-Downs.....	15-1
Cable Kinks, Wear and Interference.....	15-2
Propeller Shaft Log.....	15-2
Fuel System Leaks	15-3
Exhaust System Leaks	15-3
Fully Charged Battery.....	15-4
Quarterly Maintenance	15-5
Engine Starter Gear and Shaft Lubrication.....	15-5
Annual Maintenance.....	15-5
Check Engine Mounts	15-6
Check Propeller Shaft Coupling Alignment.....	15-6
Inspect Exhaust Flaps	15-6
Lubricate Steering System	15-6
Lubricate Shift and Throttle System	15-7
Ballast Pump Impeller.....	15-7
Inspect Complete Fuel System for Leakage.....	15-8
Storage/Winterization	16-1
General Preparation	16-1
Fuel System Treatment	17-1
General Power Package Preparation	16-2
Other Winterization Preparation	16-2
Ballast System Preparations	16-2
Reactivating After Storage.....	16-2
Propeller Maintenance.....	17-1
Guide to Troubleshooting	18-1
Limited Warranty Statement.....	19-1
Warranty Transfer	20-1
Genuine MasterCraft Parts.....	21-1
Service Log.....	22-1

