

Instructions for Installing the Illusion XS Tow Bar



Align protruding ½" bolt into tapered mount. Insert special allen wrench included with tower into opening located on outside radius of tow bar. Tighten bolt about halfway down using 3/8" socket with ratchet wrench.



Tighten bolt until firmly secured.



Align the opposing side bolt by flexing the bow in or out and insert bolt into hole.



Return to opposite bolt and finish tightening.
Torque bolts to 50 lbs.