



- 1) REMOVE EXISTING RETURN LINE FROM CIRC. PUMP AND PLUG W/1/2" MPT BRASS OR GALVANIZED PLUG. (IF APPLICABLE)
- 2) FIND RAW WATER PUMP INTAKE LINE AND REMOVE A 5/8" SECTION BETWEEN THE THRU-HULL FITTING AND THE RAW WATER PUMP.
- 3) INSTALL "Y" FITTING AS SHOWN ABOVE WITH THE 5/8" BRANCH FACING THE CORRECT DIRECTION.
- 4) TIGHTEN HOSE CLAMPS .

NOTE: AFTER REMOVING EXISTING RETURN LINE (STEP 1) BE SURE TO EXTEND THE HOSE TO THE AREA ON THE RAW WATER INTAKE LINE WHERE YOU WANT TO INSTALL THE "Y" FITTING BEFORE YOU MAKE THE CUT, TO ENSURE ENOUGH LENGTH OF HOSE.